


HOISTING PLUG – 10 TON



	ITEM DESCRIPTION	PART NUMBERS
1-9	10 TON HOISTING PLUG ASSEMBLY	38-00-100
01	SPINDLE	38-00-001
02	BEARING	38-00-002
03	BEARING HOUSING	38-00-003
04	RHRUST BEARING	38-00-004
05	CASTLE NUT	38-00-005
06	COTTER PIN	38-00-006
07	GRUB	38-00-007
08	HOISTING PLUG BODY	38-00-008
09	GREASE FITTING	16-03-024