


5 TON HOISTING PLUG



	ITEM DESCRIPTION	PART NUMBERS
1-9	5 TON HOISTING PLUG ASSEMBLY	36-00-100
01	SPINDLE	36-00-001
02	BALL BEARING	36-00-002
03	BEARING HOUSING	36-00-003
04	THRUST BEARING	36-00-004
05	CASTLE NUT	36-00-005
06	COTTER PIN	36-00-006
07	HOISTING PLUG BODY	36-00-007
08	GRUB	36-00-008
09	GREASE FITTING	16-03-024